



Model(s):	CTC CombiAir 10MR + CTC EcoLogic		
Air-to-water heat pump:	Yes	Energy efficiency class:	- -
Water-to-water heat pump:	No	Controller class:	VI -
Brine-to-water heat pump:	No	Controller contribution:	4 %
Low-temperature heat pump:	No	Package efficiency:	181 %
Equipped with a supplementary heater:	No	Package efficiency class:	- -
Heat pump combination heater:	No		

Parameters shall be declared for medium-temperature application, except for low-temperature heat pumps. For low-temperature heat pumps, parameters shall be declared for low-temperature application.

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
<b>Rated heat output (*)</b>	<i>P<sub>rated</sub></i>	<b>7</b>	kW	<b>Seasonal space heating energy efficiency</b>	$\eta_s$	<b>177</b>	%
Declared capacity for heating for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>				Declared coefficient of performance or primary energy ratio for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>			
T <sub>j</sub> = -7 °C	<i>P<sub>dh</sub></i>	-	kW	T <sub>j</sub> = -7 °C	<i>COP<sub>d</sub></i>	-	-
T <sub>j</sub> = +2 °C	<i>P<sub>dh</sub></i>	<b>6,6</b>	kW	T <sub>j</sub> = +2 °C	<i>COP<sub>d</sub></i>	<b>2,30</b>	-
T <sub>j</sub> = +7 °C	<i>P<sub>dh</sub></i>	<b>4,3</b>	kW	T <sub>j</sub> = +7 °C	<i>COP<sub>d</sub></i>	<b>3,97</b>	-
T <sub>j</sub> = +12 °C	<i>P<sub>dh</sub></i>	<b>2,3</b>	kW	T <sub>j</sub> = +12 °C	<i>COP<sub>d</sub></i>	<b>5,54</b>	-
T <sub>j</sub> = bivalent temperature	<i>P<sub>dh</sub></i>	<b>5,3</b>	kW	T <sub>j</sub> = bivalent temperature	<i>COP<sub>d</sub></i>	<b>3,42</b>	-
T <sub>j</sub> = operation limit temperature	<i>P<sub>dh</sub></i>	<b>6,6</b>	kW	T <sub>j</sub> = operation limit temperature	<i>COP<sub>d</sub></i>	<b>2,30</b>	-
For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>P<sub>dh</sub></i>	-	kW	For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>COP<sub>d</sub></i>	-	-
Bivalent temperature	<i>T<sub>biv</sub></i>	<b>5</b>	°C	For air-to-water heat pumps: Operation limit temperature	<i>TOL</i>	<b>2</b>	°C
Cycling interval capacity for heating	<i>P<sub>cych</sub></i>	-	kW	Cycling interval efficiency	<i>COP<sub>cyc</sub></i>	-	-
Degradation co-efficient	<i>C<sub>dh</sub></i>	<b>0,99</b>	-	Heating water operating limit temperature	<i>WTOL</i>	<b>60</b>	°C
Power consumption in modes other than active mode				Supplementary heater			
Off mode	<i>P<sub>OFF</sub></i>	<b>0,003</b>	kW	Rated heat output (*)	<i>P<sub>sup</sub></i>	<b>0,0</b>	kW
Thermostat-off mode	<i>P<sub>TO</sub></i>	<b>0,008</b>	kW	Type of energy input	<b>Electric</b>		
Standby mode	<i>P<sub>SB</sub></i>	<b>0,008</b>	kW				
Crankcase heater mode	<i>P<sub>CK</sub></i>	<b>0,000</b>	kW				
Other items							
Capacity control	<b>Variable</b>			For air-to-water heat pumps: Rated air flow rate, outdoors	-	<b>3000</b>	m <sup>3</sup> /h
Sound power level, indoors/outdoors	<i>L<sub>WA</sub></i>	<b>-/53</b>	dB	For water-/brine-to-water heat pumps: Rated brine or water flow rate, outdoor heat exchanger	-	-	
Annual energy consumption	<i>Q<sub>HE</sub></i>	<b>1964</b>	kWh				

For heat pump combination heater:

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
<b>Declared load profile</b>	-	<b>Efficiency class</b>	-	<b>Water heating energy efficiency</b>	$\eta_{wh}$	-	%
Daily electricity consumption	<i>Q<sub>elec</sub></i>	-	kWh	Daily fuel consumption	<i>Q<sub>fuel</sub></i>	-	kWh
Annual electricity consumption	<i>AEC</i>	-	kWh	Annual fuel consumption	<i>AFC</i>	-	GJ

Specific precautions and end of life information:

The packaging must be deposited at a recycling station or with the installation engineer for correct waste management. At the end of the product's life cycle, it must be sent correctly to a waste station or reseller offering a service of that type. It is of great importance that the product's refrigerant, compressor oil and electrical/electronic equipment are properly disposed of. Disposing of the product as household waste is not permitted.

Contact details

CTC AB, Box 309, SE-341 26 Ljungby Tel +46 372 88000

www.ctc.se

F0141

231218

**Warm climate and Low temperature**

Model(s):	CTC CombiAir 10MR + CTC EcoLogic		
Air-to-water heat pump:	Yes	Energy efficiency class:	- -
Water-to-water heat pump:	No	Controller class:	VI -
Brine-to-water heat pump:	No	Controller contribution:	4 %
Low-temperature heat pump:	No	Package efficiency:	264 %
Equipped with a supplementary heater:	No	Package efficiency class:	- -
Heat pump combination heater:	No		

Parameters shall be declared for medium-temperature application, except for low-temperature heat pumps. For low-temperature heat pumps, parameters shall be declared for low-temperature application.

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
<b>Rated heat output (*)</b>	<i>P<sub>rated</sub></i>	<b>7</b>	kW	<b>Seasonal space heating energy efficiency</b>	$\eta_s$	<b>260</b>	%
Declared capacity for heating for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>				Declared coefficient of performance or primary energy ratio for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>			
T <sub>j</sub> = -7 °C	<i>P<sub>dh</sub></i>	-	kW	T <sub>j</sub> = -7 °C	<i>COP<sub>d</sub></i>	-	-
T <sub>j</sub> = +2 °C	<i>P<sub>dh</sub></i>	<b>6,9</b>	kW	T <sub>j</sub> = +2 °C	<i>COP<sub>d</sub></i>	<b>3,17</b>	-
T <sub>j</sub> = +7 °C	<i>P<sub>dh</sub></i>	<b>4,5</b>	kW	T <sub>j</sub> = +7 °C	<i>COP<sub>d</sub></i>	<b>6,08</b>	-
T <sub>j</sub> = +12 °C	<i>P<sub>dh</sub></i>	<b>2,6</b>	kW	T <sub>j</sub> = +12 °C	<i>COP<sub>d</sub></i>	<b>8,05</b>	-
T <sub>j</sub> = bivalent temperature	<i>P<sub>dh</sub></i>	<b>5,3</b>	kW	T <sub>j</sub> = bivalent temperature	<i>COP<sub>d</sub></i>	<b>4,98</b>	-
T <sub>j</sub> = operation limit temperature	<i>P<sub>dh</sub></i>	<b>6,9</b>	kW	T <sub>j</sub> = operation limit temperature	<i>COP<sub>d</sub></i>	<b>3,17</b>	-
For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>P<sub>dh</sub></i>	-	kW	For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>COP<sub>d</sub></i>	-	-
Bivalent temperature	<i>T<sub>biv</sub></i>	<b>5</b>	°C	For air-to-water heat pumps: Operation limit temperature	<i>TOL</i>	<b>2</b>	°C
Cycling interval capacity for heating	<i>P<sub>cych</sub></i>	-	kW	Cycling interval efficiency	<i>COP<sub>cyc</sub></i>	-	-
Degradation co-efficient	<i>C<sub>dh</sub></i>	<b>0,99</b>	-	Heating water operating limit temperature	<i>WTOL</i>	<b>60</b>	°C
Power consumption in modes other than active mode				Supplementary heater			
Off mode	<i>P<sub>OFF</sub></i>	<b>0,003</b>	kW	Rated heat output (*)	<i>P<sub>sup</sub></i>	<b>0,0</b>	kW
Thermostat-off mode	<i>P<sub>TO</sub></i>	<b>0,012</b>	kW	Type of energy input <b>Electric</b>			
Standby mode	<i>P<sub>SB</sub></i>	<b>0,008</b>	kW				
Crankcase heater mode	<i>P<sub>CK</sub></i>	<b>0,000</b>	kW	For air-to-water heat pumps: Rated air flow rate, outdoors			
Other items				For water-/brine-to-water heat pumps: Rated brine or water flow rate, outdoor heat exchanger			
Capacity control	<b>Variable</b>			-	<b>3000</b>	<i>m<sup>3</sup>/h</i>	
Sound power level, indoors/ outdoors	<i>L<sub>WA</sub></i>	<b>-/53</b>	<i>dB</i>	-	<b>-</b>	<i>m<sup>3</sup>/h</i>	
Annual energy consumption	<i>Q<sub>HE</sub></i>	<b>1379</b>	<i>kWh</i>				

For heat pump combination heater:

<b>Declared load profile</b>	-	<b>Efficiency class</b>	-	<b>Water heating energy efficiency</b>	$\eta_{wh}$	-	%
Daily electricity consumption	<i>Q<sub>elec</sub></i>	-	kWh	Daily fuel consumption	<i>Q<sub>fuel</sub></i>	-	kWh
Annual electricity consumption	<i>AEC</i>	-	kWh	Annual fuel consumption	<i>AFC</i>	-	GJ

Specific precautions and end of life information:

The packaging must be deposited at a recycling station or with the installation engineer for correct waste management. At the end of the product's life cycle, it must be sent correctly to a waste station or reseller offering a service of that type. It is of great importance that the product's refrigerant, compressor oil and electrical/electronic equipment are properly disposed of. Disposing of the product as household waste is not permitted.

Contact details

CTC AB, Box 309, SE-341 26 Ljungby Tel +46 372 88000

www.ctc.se

F0141

231218

## Average climate and Medium temperature

Ljungby

Model(s):	CTC CombiAir 10MR + CTC EcoLogic		
Air-to-water heat pump:	Yes	Energy efficiency class:	A++ -
Water-to-water heat pump:	No	Controller class:	VI -
Brine-to-water heat pump:	No	Controller contribution:	4 %
Low-temperature heat pump:	No	Package efficiency:	136 %
Equipped with a supplementary heater:	No	Package efficiency class:	A++ -
Heat pump combination heater:	No		

Parameters shall be declared for medium-temperature application, except for low-temperature heat pumps. For low-temperature heat pumps, parameters shall be declared for low-temperature application.

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
<b>Rated heat output (*)</b>	<i>Prated</i>	<b>6</b>	kW	<b>Seasonal space heating energy efficiency</b>	$\eta_s$	<b>132</b>	%
Declared capacity for heating for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>				Declared coefficient of performance or primary energy ratio for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>			
T <sub>j</sub> = -7 °C	<i>P<sub>dh</sub></i>	<b>5,8</b>	kW	T <sub>j</sub> = -7 °C	<i>COP<sub>d</sub></i>	<b>1,98</b>	-
T <sub>j</sub> = +2 °C	<i>P<sub>dh</sub></i>	<b>3,5</b>	kW	T <sub>j</sub> = +2 °C	<i>COP<sub>d</sub></i>	<b>3,17</b>	-
T <sub>j</sub> = +7 °C	<i>P<sub>dh</sub></i>	<b>2,3</b>	kW	T <sub>j</sub> = +7 °C	<i>COP<sub>d</sub></i>	<b>4,98</b>	-
T <sub>j</sub> = +12 °C	<i>P<sub>dh</sub></i>	<b>2,2</b>	kW	T <sub>j</sub> = +12 °C	<i>COP<sub>d</sub></i>	<b>5,50</b>	-
T <sub>j</sub> = bivalent temperature	<i>P<sub>dh</sub></i>	<b>5,8</b>	kW	T <sub>j</sub> = bivalent temperature	<i>COP<sub>d</sub></i>	<b>1,98</b>	-
T <sub>j</sub> = operation limit temperature	<i>P<sub>dh</sub></i>	<b>5,8</b>	kW	T <sub>j</sub> = operation limit temperature	<i>COP<sub>d</sub></i>	<b>1,69</b>	-
For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>P<sub>dh</sub></i>	-	kW	For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>COP<sub>d</sub></i>	-	-
Bivalent temperature	<i>T<sub>biv</sub></i>	<b>-7</b>	°C	For air-to-water heat pumps: Operation limit temperature	<i>TOL</i>	<b>-10</b>	°C
Cycling interval capacity for heating	<i>P<sub>cych</sub></i>	-	kW	Cycling interval efficiency	<i>COP<sub>cy</sub></i>	-	-
Degradation co-efficient	<i>C<sub>dh</sub></i>	<b>0,99</b>	-	Heating water operating limit temperature	<i>WTOL</i>	<b>60</b>	°C
Power consumption in modes other than active mode				Supplementary heater			
Off mode	<i>P<sub>OFF</sub></i>	<b>0,003</b>	kW	Rated heat output (*)	<i>P<sub>sup</sub></i>	<b>0,7</b>	kW
Thermostat-off mode	<i>P<sub>TO</sub></i>	<b>0,008</b>	kW	Type of energy input	<b>Electric</b>		
Standby mode	<i>P<sub>SB</sub></i>	<b>0,008</b>	kW				
Crankcase heater mode	<i>P<sub>CK</sub></i>	<b>0,000</b>	kW				
Other items							
Capacity control	<b>Variable</b>			For air-to-water heat pumps: Rated air flow rate, outdoors	-	<b>3000</b>	m <sup>3</sup> /h
Sound power level, indoors/outdoors	<i>L<sub>WA</sub></i>	<b>-/53</b>	dB	For water-/brine-to-water heat pumps: Rated brine or water flow rate, outdoor heat exchanger	-	-	m <sup>3</sup> /h
Annual energy consumption	<i>Q<sub>HE</sub></i>	<b>3961</b>	kWh				

For heat pump combination heater:

Declared load profile	-	Efficiency class	-	Water heating energy efficiency	$\eta_{wh}$	-	%
Daily electricity consumption	<i>Q<sub>elec</sub></i>	-	kWh	Daily fuel consumption	<i>Q<sub>fuel</sub></i>	-	kWh
Annual electricity consumption	<i>AEC</i>	-	kWh	Annual fuel consumption	<i>AFC</i>	-	GJ

Specific precautions and end of life information:

The packaging must be deposited at a recycling station or with the installation engineer for correct waste management. At the end of the product's life cycle, it must be sent correctly to a waste station or reseller offering a service of that type. It is of great importance that the product's refrigerant, compressor oil and electrical/electronic equipment are properly disposed of. Disposing of the product as household waste is not permitted.

Contact details

CTC AB, Box 309, SE-341 26 Ljungby Tel +46 372 88000

www.ctc.se

F0141

231218

**Average climate and Low temperature**

Ljungby

Model(s):	CTC CombiAir 10MR + CTC EcoLogic		
Air-to-water heat pump:	Yes	Energy efficiency class:	A+++ -
Water-to-water heat pump:	No	Controller class:	VI -
Brine-to-water heat pump:	No	Controller contribution:	4 %
Low-temperature heat pump:	No	Package efficiency:	185 %
Equipped with a supplementary heater:	No	Package efficiency class:	A+++ -
Heat pump combination heater:	No		

Parameters shall be declared for medium-temperature application, except for low-temperature heat pumps. For low-temperature heat pumps, parameters shall be declared for low-temperature application.

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
<b>Rated heat output (*)</b>	<i>P<sub>rated</sub></i>	<b>6</b>	kW	<b>Seasonal space heating energy efficiency</b>	$\eta_s$	<b>181</b>	%
Declared capacity for heating for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>				Declared coefficient of performance or primary energy ratio for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>			
T <sub>j</sub> = -7 °C	<i>P<sub>dh</sub></i>	<b>5,6</b>	kW	T <sub>j</sub> = -7 °C	<i>COP<sub>d</sub></i>	<b>3,01</b>	-
T <sub>j</sub> = +2 °C	<i>P<sub>dh</sub></i>	<b>3,2</b>	kW	T <sub>j</sub> = +2 °C	<i>COP<sub>d</sub></i>	<b>4,20</b>	-
T <sub>j</sub> = +7 °C	<i>P<sub>dh</sub></i>	<b>2,3</b>	kW	T <sub>j</sub> = +7 °C	<i>COP<sub>d</sub></i>	<b>6,48</b>	-
T <sub>j</sub> = +12 °C	<i>P<sub>dh</sub></i>	<b>2,6</b>	kW	T <sub>j</sub> = +12 °C	<i>COP<sub>d</sub></i>	<b>8,05</b>	-
T <sub>j</sub> = bivalent temperature	<i>P<sub>dh</sub></i>	<b>6,3</b>	kW	T <sub>j</sub> = bivalent temperature	<i>COP<sub>d</sub></i>	<b>2,61</b>	-
T <sub>j</sub> = operation limit temperature	<i>P<sub>dh</sub></i>	<b>6,3</b>	kW	T <sub>j</sub> = operation limit temperature	<i>COP<sub>d</sub></i>	<b>2,61</b>	-
For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>P<sub>dh</sub></i>	-	kW	For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>COP<sub>d</sub></i>	-	-
Bivalent temperature	<i>T<sub>biv</sub></i>	<b>-10</b>	°C	For air-to-water heat pumps: Operation limit temperature	<i>TOL</i>	<b>-10</b>	°C
Cycling interval capacity for heating	<i>P<sub>cych</sub></i>	-	kW	Cycling interval efficiency	<i>COP<sub>cyc</sub></i>	-	-
Degradation co-efficient	<i>C<sub>dh</sub></i>	<b>0,99</b>	-	Heating water operating limit temperature	<i>WTOL</i>	<b>60</b>	°C
Power consumption in modes other than active mode				Supplementary heater			
Off mode	<i>P<sub>OFF</sub></i>	<b>0,003</b>	kW	Rated heat output (*)	<i>P<sub>sup</sub></i>	<b>0,0</b>	kW
Thermostat-off mode	<i>P<sub>TO</sub></i>	<b>0,012</b>	kW	Type of energy input <b>Electric</b>			
Standby mode	<i>P<sub>SB</sub></i>	<b>0,008</b>	kW				
Crankcase heater mode	<i>P<sub>CK</sub></i>	<b>0,000</b>	kW	For air-to-water heat pumps: Rated air flow rate, outdoors			
Capacity control	<b>Variable</b>			For water-/brine-to-water heat pumps: Rated brine or water flow rate, outdoor heat exchanger			
Sound power level, indoors/ outdoors	<i>L<sub>WA</sub></i>	<b>-/53</b>	dB				
Annual energy consumption	<i>Q<sub>HE</sub></i>	<b>2834</b>	kWh				

For heat pump combination heater:

<b>Declared load profile</b>	-	<b>Efficiency class</b>	-	<b>Water heating energy efficiency</b>	$\eta_{wh}$	-	%
Daily electricity consumption	<i>Q<sub>elec</sub></i>	-	kWh	Daily fuel consumption	<i>Q<sub>fuel</sub></i>	-	kWh
Annual electricity consumption	<i>AEC</i>	-	kWh	Annual fuel consumption	<i>AFC</i>	-	GJ

Specific precautions and end of life information:

The packaging must be deposited at a recycling station or with the installation engineer for correct waste management. At the end of the product's life cycle, it must be sent correctly to a waste station or reseller offering a service of that type. It is of great importance that the product's refrigerant, compressor oil and electrical/electronic equipment are properly disposed of. Disposing of the product as household waste is not permitted.

Contact details

CTC AB, Box 309, SE-341 26 Ljungby Tel +46 372 88000

www.ctc.se

F0141

231218



Model(s):	CTC CombiAir 10MR + CTC EcoLogic		
Air-to-water heat pump:	Yes	Energy efficiency class:	- -
Water-to-water heat pump:	No	Controller class:	VI -
Brine-to-water heat pump:	No	Controller contribution:	4 %
Low-temperature heat pump:	No	Package efficiency:	118 %
Equipped with a supplementary heater:	No	Package efficiency class:	- -
Heat pump combination heater:	No		

Parameters shall be declared for medium-temperature application, except for low-temperature heat pumps. For low-temperature heat pumps, parameters shall be declared for low-temperature application.

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
<b>Rated heat output (*)</b>	<i>P<sub>rated</sub></i>	<b>6</b>	kW	<b>Seasonal space heating energy efficiency</b>	$\eta_s$	<b>114</b>	%
Declared capacity for heating for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>				Declared coefficient of performance or primary energy ratio for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>			
T <sub>j</sub> = -7 °C	<i>P<sub>dh</sub></i>	<b>4,0</b>	kW	T <sub>j</sub> = -7 °C	<i>COP<sub>d</sub></i>	<b>2,53</b>	-
T <sub>j</sub> = +2 °C	<i>P<sub>dh</sub></i>	<b>2,4</b>	kW	T <sub>j</sub> = +2 °C	<i>COP<sub>d</sub></i>	<b>3,45</b>	-
T <sub>j</sub> = +7 °C	<i>P<sub>dh</sub></i>	<b>1,9</b>	kW	T <sub>j</sub> = +7 °C	<i>COP<sub>d</sub></i>	<b>4,58</b>	-
T <sub>j</sub> = +12 °C	<i>P<sub>dh</sub></i>	<b>2,3</b>	kW	T <sub>j</sub> = +12 °C	<i>COP<sub>d</sub></i>	<b>5,67</b>	-
T <sub>j</sub> = bivalent temperature	<i>P<sub>dh</sub></i>	<b>5,0</b>	kW	T <sub>j</sub> = bivalent temperature	<i>COP<sub>d</sub></i>	<b>1,71</b>	-
T <sub>j</sub> = operation limit temperature	<i>P<sub>dh</sub></i>	<b>5,0</b>	kW	T <sub>j</sub> = operation limit temperature	<i>COP<sub>d</sub></i>	<b>1,44</b>	-
For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>P<sub>dh</sub></i>	<b>5,0</b>	kW	For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>COP<sub>d</sub></i>	<b>1,71</b>	-
Bivalent temperature	<i>T<sub>biv</sub></i>	<b>-15</b>	°C	For air-to-water heat pumps: Operation limit temperature	<i>TOL</i>	<b>-20</b>	°C
Cycling interval capacity for heating	<i>P<sub>cych</sub></i>	-	kW	Cycling interval efficiency	<i>COP<sub>cyc</sub></i>	-	-
Degradation co-efficient	<i>C<sub>dh</sub></i>	<b>0,99</b>	-	Heating water operating limit temperature	<i>WTOL</i>	<b>60</b>	°C
Power consumption in modes other than active mode				Supplementary heater			
Off mode	<i>P<sub>OFF</sub></i>	<b>0,003</b>	kW	Rated heat output (*)	<i>P<sub>sup</sub></i>	<b>6,2</b>	kW
Thermostat-off mode	<i>P<sub>TO</sub></i>	<b>0,008</b>	kW	Type of energy input	<b>Electric</b>		
Standby mode	<i>P<sub>SB</sub></i>	<b>0,008</b>	kW				
Crankcase heater mode	<i>P<sub>CK</sub></i>	<b>0,000</b>	kW				
Other items							
Capacity control	<b>Variable</b>			For air-to-water heat pumps: Rated air flow rate, outdoors	-	<b>3000</b>	m <sup>3</sup> /h
Sound power level, indoors/ outdoors	<i>L<sub>WA</sub></i>	<b>-/53</b>	dB	For water-/brine-to-water heat pumps: Rated brine or water flow rate, outdoor heat exchanger	-	<b>-</b>	m <sup>3</sup> /h
Annual energy consumption	<i>Q<sub>HE</sub></i>	<b>5204</b>	kWh				

For heat pump combination heater:

Declared load profile	-	Efficiency class	-	Water heating energy efficiency	$\eta_{wh}$	-	%
Daily electricity consumption	<i>Q<sub>elec</sub></i>	-	kWh	Daily fuel consumption	<i>Q<sub>fuel</sub></i>	-	kWh
Annual electricity consumption	<i>AEC</i>	-	kWh	Annual fuel consumption	<i>AFC</i>	-	GJ

Specific precautions and end of life information:

The packaging must be deposited at a recycling station or with the installation engineer for correct waste management. At the end of the product's life cycle, it must be sent correctly to a waste station or reseller offering a service of that type. It is of great importance that the product's refrigerant, compressor oil and electrical/electronic equipment are properly disposed of. Disposing of the product as household waste is not permitted.

Contact details

CTC AB, Box 309, SE-341 26 Ljungby Tel +46 372 88000

www.ctc.se

F0141

231218

**Cold climate and Low temperature**

Ljungby

Model(s):	CTC CombiAir 10MR + CTC EcoLogic		
Air-to-water heat pump:	Yes	Energy efficiency class:	- -
Water-to-water heat pump:	No	Controller class:	VI -
Brine-to-water heat pump:	No	Controller contribution:	4 %
Low-temperature heat pump:	No	Package efficiency:	159 %
Equipped with a supplementary heater:	No	Package efficiency class:	- -
Heat pump combination heater:	No		

Parameters shall be declared for medium-temperature application, except for low-temperature heat pumps. For low-temperature heat pumps, parameters shall be declared for low-temperature application.

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
<b>Rated heat output (*)</b>	<i>P<sub>rated</sub></i>	<b>7</b>	kW	<b>Seasonal space heating energy efficiency</b>	$\eta_s$	<b>155</b>	%
Declared capacity for heating for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>				Declared coefficient of performance or primary energy ratio for part load at indoor temperature 20 °C and outdoor temperature T <sub>j</sub>			
T <sub>j</sub> = -7 °C	<i>P<sub>dh</sub></i>	<b>4,0</b>	kW	T <sub>j</sub> = -7 °C	<i>COP<sub>d</sub></i>	<b>3,43</b>	-
T <sub>j</sub> = +2 °C	<i>P<sub>dh</sub></i>	<b>2,5</b>	kW	T <sub>j</sub> = +2 °C	<i>COP<sub>d</sub></i>	<b>4,42</b>	-
T <sub>j</sub> = +7 °C	<i>P<sub>dh</sub></i>	<b>2,2</b>	kW	T <sub>j</sub> = +7 °C	<i>COP<sub>d</sub></i>	<b>6,71</b>	-
T <sub>j</sub> = +12 °C	<i>P<sub>dh</sub></i>	<b>2,6</b>	kW	T <sub>j</sub> = +12 °C	<i>COP<sub>d</sub></i>	<b>8,05</b>	-
T <sub>j</sub> = bivalent temperature	<i>P<sub>dh</sub></i>	<b>5,4</b>	kW	T <sub>j</sub> = bivalent temperature	<i>COP<sub>d</sub></i>	<b>2,42</b>	-
T <sub>j</sub> = operation limit temperature	<i>P<sub>dh</sub></i>	<b>5,8</b>	kW	T <sub>j</sub> = operation limit temperature	<i>COP<sub>d</sub></i>	<b>2,28</b>	-
For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>P<sub>dh</sub></i>	<b>5,4</b>	kW	For air-to-water heat pumps: T <sub>j</sub> = -15 °C (if TOL < -20 °C)	<i>COP<sub>d</sub></i>	<b>2,42</b>	-
Bivalent temperature	<i>T<sub>biv</sub></i>	<b>-15</b>	°C	For air-to-water heat pumps: Operation limit temperature	<i>TOL</i>	<b>-20</b>	°C
Cycling interval capacity for heating	<i>P<sub>cych</sub></i>	-	kW	Cycling interval efficiency	<i>COP<sub>cy</sub></i>	-	-
Degradation co-efficient	<i>C<sub>dh</sub></i>	<b>0,99</b>	-	Heating water operating limit temperature	<i>WTOL</i>	<b>60</b>	°C
Power consumption in modes other than active mode				Supplementary heater			
Off mode	<i>P<sub>OFF</sub></i>	<b>0,003</b>	kW	Rated heat output (*)	<i>P<sub>sup</sub></i>	<b>6,5</b>	kW
Thermostat-off mode	<i>P<sub>TO</sub></i>	<b>0,012</b>	kW	Type of energy input	<b>Electric</b>		
Standby mode	<i>P<sub>SB</sub></i>	<b>0,008</b>	kW				
Crankcase heater mode	<i>P<sub>CK</sub></i>	<b>0,000</b>	kW				
Other items							
Capacity control	<b>Variable</b>			For air-to-water heat pumps: Rated air flow rate, outdoors	-	<b>3000</b>	m <sup>3</sup> /h
Sound power level, indoors/ outdoors	<i>L<sub>WA</sub></i>	<b>-/53</b>	dB	For water-/brine-to-water heat pumps: Rated brine or water flow rate, outdoor heat exchanger	-	-	m <sup>3</sup> /h
Annual energy consumption	<i>Q<sub>HE</sub></i>	<b>4059</b>	kWh				

For heat pump combination heater:

<b>Declared load profile</b>	-	<b>Efficiency class</b>	-	<b>Water heating energy efficiency</b>	$\eta_{wh}$	-	%
Daily electricity consumption	<i>Q<sub>elec</sub></i>	-	kWh	Daily fuel consumption	<i>Q<sub>fuel</sub></i>	-	kWh
Annual electricity consumption	<i>AEC</i>	-	kWh	Annual fuel consumption	<i>AFC</i>	-	GJ

Specific precautions and end of life information:

The packaging must be deposited at a recycling station or with the installation engineer for correct waste management. At the end of the product's life cycle, it must be sent correctly to a waste station or reseller offering a service of that type. It is of great importance that the product's refrigerant, compressor oil and electrical/electronic equipment are properly disposed of. Disposing of the product as household waste is not permitted.

Contact details

CTC AB, Box 309, SE-341 26 Ljungby Tel +46 372 88000

www.ctc.se

F0141

231218